

SUTPHEN CORPORATION

SALES TECHNICAL BULLETIN

LIGHT TOWER POSITIONING

OVERVIEW

Going forward, if a Light Tower is installed on a truck, it will be wired to a light in the cab interior warning light bar. This light will illuminate if the parking brake is released and the Light Tower is not in the stowed position. This will eliminate the risk of the light bar being damaged while the truck is in motion.

STB-0011 - LIGHT TOWER POSITIONING